

NS-X40 / NS-X4

①



ベースステーション
(NS-X40)

②



カメラアダプター
(NS-X4)

③



ACケーブル

④



BNCケーブル
30 c m × 4

⑤



BNCケーブル
100 c m

⑥



8Pリモートケーブル
(ソニー用)

⑦

取扱説明書

⑧

⑨

⑩

⑪

⑫

⑬

⑭

⑮

⑯

⑰

⑱